


Remington Polesaw

Model Numbers
104317



Part No.	Description
104301S	Chain
077525S	Switch
107481-01	Armature (fan)
075837	Field
075676	Sprocket Roller Bearing
107713-01	Sprocket Gear (nylon)
059606	Drive Gear (metal)
079084-01	Oil Cap
077115	Adjustment Plate Assembly
076647	Holder/Brush Assembly
110731-01	Pole
107551-01	Bracket
104302-015	Guide Bar
108639-01	Oil Reservoir and Cap Assembly
108626-01	Handguard
110731-01	Pole & Coupling
107551-01	8" Hardware/Bracket
079882-01	10" Hardware/Bracket

*Powercord replaced with pole only

PHP